



PATIO HEATER OPERATING INSTRUCTIONS

This patio heater is designed to provide reflected heat to warm an area of approximately 16' diameter, according to the manufacturer.

Assembly: If not already assembled for you, assembly is easy.

- Secure the reflector dome to the top brackets with the hardware provided. Do not over tighten.
- Attach the legs by inserting them into the pipes, until they click into place.
- Attach the gas tank to the folding support arms on each leg. The tank should fit securely into the slots.
- Couple quick connector on heater gas line to the quick connector at the end of gas regulator hose. The quick connectors should be secure with a click.
- Locate the gas tank securing wire and attach it to the gas tank.
- Drape skirt around legs, and zip closed.

Igniting the Heater:

- Turn on the gas. Undo the skirt. Check that the gas tank fittings are secure. Turn on the gas by hand. Close the skirt.
- Light a match and position it just under the pierced heat emitter shield.
- Push heat control knob in and turn it counter clockwise until it stops. Gas will ignite and start burning just below the emitter shield.
- Do not release the knob when the gas ignites. **KEEP THE KNOB DEPRESSED FOR 20 SECONDS AND RELEASE SLOWLY.** Observe the burner to see that the flame stays lit. If the flame is extinguished, repeat the above steps. Use the control knob to adjust the flame.

Turning the Heater Off:

- Close the gas tank valve by hand. Burner will extinguish. Turn the control knob to closed position.

WARNINGS

Position only on a level surface. Let unit cool 20 minutes before touching. Always have valves turned OFF when not in use. Do not leave unit in wind or rain.

Contact us anytime for questions regarding the use of this equipment.

Monday - Friday 8-5, Saturday 8-Noon 972-381-8000
Fort Worth Location Closed Saturday
Extended Service Hours 469-576-3747